

Condenser Foam Implementation Guide for Fistreem III 8L/Hr Still

Step 01

Ensure the Still is turned off and has cooled down.

Step 02

Remove front panel.



Step 03

Find the foam in the accessory pack and carefully peel the paper off the tape (avoid tearing the foam). Then slightly squash the foam to fit.



Step 04

Stick the foam on the inside of the top hood facing opposite of the condenser ensuring it is aligned to the face of the condenser.



Step 05

Replace the front panel.

